



Contents: Metal salts and organic acids.

KEEP OUT OF REACH OF CHILDREN
DANGER

FIRST AID MEASURES: IF INHALED: Supply fresh air. If required, provide artificial respiration. Keep patient warm. Seek immediate medical advice. **IF ON SKIN:** Immediately wash with water and soap and rinse thoroughly. Seek immediate medical advice. **IF IN EYES:** Rinse opened eye for several minutes under running water. Then consult a doctor. **IF SWALLOWED:** Seek immediate medical advice.

USE WITH ADEQUATE VENTILATION
WASH THOROUGHLY AFTER HANDLING

WellClean Application Chart (Required Packets)

Well Casing Diameter (inches)

Water Depth* (feet)	Well Casing Diameter (inches)					
	4	6	8	10	12	24
50	1	3	5	8	11	44
75	2	4	7	11	16	65
100	2	5	10	15	22	87
125	3	7	12	19	27	109
150	4	8	15	23	33	131
175	4	10	17	26	38	152
200	5	11	19	30	44	174
225	5	12	22	34	49	196
250	6	14	24	38	54	218
275	7	15	27	42	60	239
300	7	16	29	45	65	261

30g NET



Directions for Use

!Caution! Inhaling, swallowing, and contact with skin or eyes should be avoided.

Read and follow all instructions.

The well water should be free of any chemical residual.

One 30g packet treats 100L or 26.4 gallons of water.

Make certain the pump is in the off position. See WellClean Application Chart to determine the total number of 30 gram packets required for the well. Mix the contents of each packet with 2.5 gallons of water. Allow to dissolve. Pour the solution into the annular space between the riser and the casing. Once the total number of packets have been dissolved and poured into the well, pour at least 2.5 gallons of water into the well to wash down any WellClean from the sides of the well casing and the riser. Start the pump momentarily to bring a portion of the solution into the pump. Leave the pump off for 12-24 hours. Pump water to waste until the silver concentration is less than 100 ppb using a silver test kit. See kit for instructions.

*Water Depth = Well Depth - Static Water Level

Made in the USA by:

BERRY SYSTEMS, INC.



Berry Systems, Inc.
926 Carolina Drive
Lugoff, SC 29078

www.berrysystemsinc.com